

C2R-FRD1 Tech Brief

Fix For:
“No Audio when using the C2R-FRD1”



Problem:

When using the C2R-FRD1 in 2009 Ford / Lincoln / Mercury vehicles with an amplified system, other than Sony or THX, audio is not present. This is due to the turn-on lead being located in a different position.

Solution:

Follow these steps to turn the factory amplifier on:

1. Locate the 24 pin main power harness in the vehicle.
2. Locate the Yellow/Purple wire in pin 7 of the main power harness in the vehicle.
3. Connect a jumper wire from the Yellow/Purple wire in the vehicle harness to the White/Green wire which connects from the C2R-FRD1 module to the 8 pin sub connector.

Connectors are viewed from wire side

