

Optional: CAPTURING SHORT CLIPS USING GESTURE-TRIGGERED VIDEOS

The DCR can capture short clips of your trip by recognizing your gestures. See something interesting during your trip? Take a Gesture-Triggered video of the event and save it right to your account for easy sharing.

With an open palm, move your hand towards the DCRCAM to capture a 20-second recording (10 seconds prior to your hand motion and 10 seconds after). The screen will flash and a brief tone will sound indicating that the gesture has been recognized. A countdown timer will appear on the screen indicating how much time remains on the recording.

TIP: If you would like to capture a longer event, repeat the gesture and it will continue recording.

